

### PARTS LIST

- |  |   |   |
|--|---|---|
| 1. Outer Housing Assembly (1 each)                             | 6. Lever Handle with Set Screw (2 each) | 15. Dead Bolt (1 each)                  |
| 2. Water Seal (1 each)   | 7. Remote Controllers (2 each)          | 16. Battery Housing (1 each)            |
| 3. Spindle, Spring Latch / <b>Passage Function</b> (1 each)    | 8. Inner Housing Assembly (1 each)      | 17. 4mmx20mm Wood Screw (8 each)        |
| 3.1 Spindle, Spring Latch / <b>Storeroom Function</b> (1 each) | 9. M5-0.8P Machine Screw (4 each)       | 18. Spring Latch (1 each)               |
| 4. Nylon Washer (2 each)                                       | 10. Push Pin                            | 19. Tailpiece, Dead Bolt (1 each)       |
| 5. 2.5mm Allen Wrench (1 each)                                 | 11. Inner Escutcheon (1 each)           | 20. Coil Spring (1 each)                |
|  | 12. M3-0.5P Machine Screw (2 each)      | 21. Plastic Snap Bushing (1 each)       |
|  | 13. 2mm (2 each)                        | 22. Strike Plate, Dead Bolt (1 each)    |
|  | 14. Indicator (1 each)                  | 23. Strike Plate, Spring Latch (1 each) |

